

BEDRUG, Inc.

BEDRUG® MAT FOR DROP-IN LINER

INSTALLATION INSTRUCTIONS

WARNING: IMPROPER INSTALLATION WILL RESULT IN LINER FLYING OUT OF THE TRUCK! FOLLOW INSTRUCTIONS EXACTLY!

APPROXIMATE INITIAL INSTALLATION TIME LESS THAN 30 MINUTES
READ COMPLETE INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

1. (15) tree fasteners are included with the Mat. A hammer, awl, punch, drill, drill stop and a 1/4" drill bit are required for installation. Use a sharp utility knife for cutting material if needed.
2. Mats are designed to fit most major brands of drop-in liners. Perforations are provided in strategic areas on some models for assistance in trimming for better fit. See illustration.

NOTE: IF YOU HAVE PURCHASED A UNIVERSAL MAT, THE MAT CAN BE CUT TO FIT ANY DROP-IN LINER APPLICATION.

3. Locate the BedRug bed Mat in the bed of the truck to determine the exact location and fit.
4. a. Locate and punch holes in the Mat with an awl for fasteners. Start at the front center and work outboard and toward the rear. Be sure to locate fastener points on the top of a rib or high spot of the drop in liner to provide clearance for the tree fasteners. See illustration.
b. Center punch the fastener locations in the drop in liner using the Mat as a template.
c. Drill a 1/4" hole in the drop in liner then firmly press tree fastener into position.

NOTE: BE SURE TO USE A DRILL STOP TO PREVENT DAMAGE TO THE TRUCK BED! DO NOT ATTEMPT TO DRILL THROUGH THE MAT MATERIAL!

